

MGF/TF SEAT BELT SMART

BGF9034

Remove head restraint by twisting the plastic dome cap anti clockwise and withdraw the headrest. Slide on the seatbelt smart with the slot facing uppermost and pointing to the outside. Insert the seat belt into the guide and set the seatbelt to the desired position, adjust the guide until the belt pulls out smoothly. Tighten lockscrew.



NOTE: Incorrect fitting can cause the seat belt to jam or foul. We cannot accept liability for incorrect fitting.

> Brown & Gammons Ltd, 18 High Street, Baldock, Herts, SG7 6AS. Tel: 01462 490049 sales@ukmgparts.com